

Sigen Gateway HomeMax TP Installation Guide

Version: 04
Release date: 2025-08-19




! Caution

- Trained or experienced electrical personnel are required to operate the equipment.
- Operators should be familiar with national/regional laws, regulations and standards, the structure and working principle of relevant systems.
- Before operations, please carefully read operating requirements and precautions in this document and Important Notice. Any equipment damage caused by improper operation will not be covered under warranty.


1 Product Description

1.1 Appearance and Dimensions




1.2 Port Description

Bottom view



S/N	Name	Marking
1	Wire-in port of inverter 1	INV1
2	Wire-in port of inverter 2	INV2
3	Wire-in port of backup household loads	BACKUP
4	Wire-in port for smart loads/generator	SMART-PORT
5	Wire-in port of power grid	GRID
6	Wire-in port of communication	COM

Interior view



S/N	Label	Description
1	-	FE interfaces
2	-	RS485, DI, and DO interfaces
3	QF2	Miniature circuit breaker (Smart loads ^[1] /Generator)
4	QF1	Miniature circuit breaker (Power grid)
5	QF5	Miniature circuit breaker (Backup household loads)
6	QF6	Miniature circuit breaker + Surge protection device
7	GND	Terminal (connecting to functional ground cable)
8	-	Cable clamp
9	-	Earthing bar
10	QF3	Miniature circuit breaker (Inverters 1)
11	QF4	Miniature circuit breaker (Inverters 2)

Note [1]:

- All the power equipment in the owner's home can be connected as smart loads.
- To ensure that this product maximizes the benefits to users, it is recommended that the high-power equipment be connected as smart loads (Third-party inverter, heat pumps, pool heaters, clothes dryers, immersion heaters, etc.), which can be cut off when the energy storage system has low power. Other low-power equipment are connected as household loads (lights, routers, etc.)



Danger

Please check that all switches are turned off at the factory.
Always avoid hot-line work.

2 Pre-installation Check

- Check whether the components are entirely supplied against the packing list and whether the appearance is in good condition. For any problem, contact your sales representative.
- Parts and accessories supplied with the packing box are personal assets of the owner and must not be taken away from the installation site.
- Check personal protective equipment and installation tools to ensure that they are complete; If not, please make them up.
- Check and ensure the completeness of personal protective equipment and installation tools; replenish if necessary.
- Check if the factory-installed screws are tight. Before delivery, the tightened screws are marked with lines. If the marks are misaligned, the screws are loose. Tighten the screws again.

Protective equipment



Safety hat



Safety glasses



Dust mask



Protective gloves




Insulating gloves



Insulating shoes


Installation tool



Power drill



Vacuum cleaner



Wire cutter



Network cable pliers



Crimping pliers



Wire stripper




Scissors




Cable tie



Heat shrinkable sleeve



Heat gun



Insulation screwdriver set




Insulation sleeve set



Torque socket wrench



Marker



Level



Tape measure



Multimeter



Cold terminal crimping pliers



Adjustable torque wrench for external hexagon bolts



Utility knife




Rubber mallet

⚠ Caution

- The specifications of the Installer-provided cable must comply with the cable regulations and standards of the country/region standards.
- L1, L2, L3, N and PE should be connected to other equipment in sequence without mixing.

Installer-provided cable

S/N	Cable name		Recommended specifications
1	Functional ground cable		Outdoor single-core copper flexible cable Cross-sectional area of core conductor: 6–10 mm ²
2	AC cable	Connected to inverter	Outdoors five-core copper flexible cable (L1, L2, L3, N, PE) - SigenStor EC/Sigen Hybrid (5.0–15.0) TP: Cross-sectional area of single-core conductor: 4–6 mm²; Outer diameter: 9–25 mm. - SigenStor EC/Sigen Hybrid (17.0–20.0) TP: Cross-sectional area of single-core conductor: 6–10 mm²; Outer diameter: 9–25 mm. - SigenStor EC/Sigen Hybrid (25.0–30.0) TP: Cross-sectional area of single-core conductor: 10–16 mm²; Outer diameter: 9–25 mm. 
3		Connected to backup household loads	Outdoor five-core copper flexible cable (L1, L2, L3, N, PE) Cross-sectional area of core conductor: 35 mm ² ; Outer diameter: 19–32 mm
4		Connected to power grid	
5		Connected to smart loads/generator	
6	RJ45 network cable		Outdoor eight-conductor shielded twin-twisted pair cable Cross-sectional area of core conductor: 0.13–0.2 mm ² ; Outer diameter: 4–7.5 mm Single cable length: ≤ 100 m ^[1] RJ45 network cables are EIA/TIA 568B standard network cables
7	DI/DO signal cable (Optional)		Outdoor two-conductor shielded cable Cross-sectional area of core conductor: 0.2–1.5 mm ² Outer diameter: 2–4 mm

Note [1]: The cable length should be limited for good communication. Too long cable degrades the communication effect.

3 Site Selection Requirements

Tips

- **Before installing the equipment, be sure to read the following installation requirements carefully. The company will not bear any responsibility if the equipment malfunctions, is damaged, or even causes a personal safety accident during operation due to failure to operate as required.**
- **During actual installation, the selection of the mounting location should meet local fire protection, environmental protection, and other regulations, as well as local low-voltage power distribution room technical specifications. The specific mounting location planning shall be subject to the installer or EPC (Engineering, Procurement, Construction).**

Installation environment


- Do not install the equipment in smoky, flammable, or explosive environments.
- Avoid exposing the equipment to direct sunlight, rain, standing water, snow, or dust. Install the equipment in a sheltered place. Take preventive measures in operating areas prone to natural disasters such as floods, mudslides, earthquakes, and typhoons.
- Do not install the equipment in an environment with strong electromagnetic interference.
- Ensure that the temperature and humidity of the installation environment comply with the equipment's requirements.
- The equipment should be installed in an area that is at least 500 m away from corrosion sources that may result in salt damage or acid damage (corrosion sources include but are not limited to seaside, thermal power plants, chemical plants, smelters, coal plants, rubber plants, and electroplating plants).
- In areas with good marine environments (such as Norway, where the nearshore salinity is ≤ 28 psu), the mounting distance of the device from the coastline can be appropriately relaxed to ≥ 200 m.
- If the outer surface of the device is damaged, please repaint the device in time.

Installation position

- Do not tilt or overturn the equipment to ensure that it is installed horizontally.
- Do not install the equipment in places easily touched by children.
- Do not install the equipment in places with fire or damp.
- Please keep away from the daily work and living places.
- Do not install the equipment in a sealed, poorly ventilated location without fire protection measures and difficult access for firefighters.
- The equipment is hot when it is running. If the equipment is installed indoors, please ensure good indoor ventilation and avoid significant indoor temperature rise by 3°C while the equipment is running. Otherwise, the equipment will be derated.
- Do not install the equipment in mobile scenarios such as RVS, cruise ships, and trains.
- You are advised to install the equipment in places that are easy to access, install, operate, maintain status.
- Keep the equipment clear of vehicle passage when installed in a garage to avoid collisions.


Mounting surface

- Do not install the equipment on a flammable carrier.
- The installation carrier must meet load-bearing requirements. Solid brick-concrete structure, concrete walls is recommended.
- The surface of the installation carrier must be smooth and the installation area must meet the installation space requirements.
- No water or electricity is routed inside the carrier to prevent drilling hazards during equipment installation.




4 Equipment Installation


1



2



3




5 Cable Connection

5.1 Recommended Routing


⚠ Danger

Do not perform operations on the equipment with power on. Before operation, please make sure all power supplies to the equipment have been disconnected, including but not limited to the grid side, inverter and Generator power switches.

Solution 1: The device is reliably grounded.




Solution 2: The device is not reliably grounded.



SGA1IN00006

⚠ Caution

- Connect cables according to the corresponding labels to prevent personal injury and equipment damage caused by incorrect cable connection.
- To ensure that the inverters, loads, and the Gateway are connected to the common ground point, connect the PE cable.



AC cable



Communication cable
(FE and DI, DO)

Functional ground cable

- 1 (INV1) Connect to Inverters 1
- 2 (INV2) Connect to Inverters 2
- 3 (BACKUP) Connect to Backup household loads
- 4 (SMART-PORT) Connect to Smart loads/Generator
- 5 (GRID) Connect to Power grid
- 6 (COM) Communication cable


5.2 Opening Equipment Door

1



SGA1IN00223

2



SGA1IN00127


5.3 Functional ground cable Connection

Danger


- If the device is not reliably grounded, do not connect the functional ground cable.
- If the device is reliably grounded, the functional ground cable shall be connected.

Caution


In off-grid mode, the N wire in the system is short-connected to the functional grounding wire through the relay to create a grounding system. When earth leakage or short circuit occurs in loads, leakage protection and overcurrent protection devices are triggered to prevent these faults.



5.4 Connecting Power Grid / Backup household loads / Smart Load / Generator



5.5 Connecting Inverters




5.6 Communication port introduction

Tips


- Refer to Appearance 1 when the label bottom is printed with SGW1PWR3 and Appearance 2 when the label bottom is not printed with SGW1PWR3.
- Identify the cable connection and table content suiting you according to the label appearance.
- For the Generator that starts when the dry contacts are open, connect the dry contacts to DO3-NO and DO3-COM.
- For the Generator that starts when the dry contacts are closed, connect the dry contacts to DO3-NC and DO3-COM.

Appearance 1




Label	Definition		Description
FE (Network cable interface)	FE1	Fast Ethernet 1	Used to connect an inverter.
	FE2	Fast Ethernet 2	Used to connect an Sigen EV AC Charger, inverter, router and so on.
(Reserved)485 (RS485 interface)	PE	PE signal shielding ground	Used to connect the equipment over RS485.
	485-A	RS485 signal 2_A+	
	485-B	RS485 signal 2_B-	
DI1 (Digital input 1)	GND	Signal GND	• Universal digital input interfaces. • DI1 is used to connect the feedback contact of the bypass switch.
	DI1	Digital input 1	
DI2 (Digital input 1)	GND	Signal GND	• DI2 can be used to connect the feedback signal of the external Automatic Transfer Switch (ATS) to identify whether the gateway "grid port" is powered by the grid or the generator. • Low impedance input (short circuit on ATS relay) indicates the power grid. High impedance input (open circuit on the ATS relay) indicates the Generator.
	DI2	Digital input 2	
DO3/GEN (Dry contact 3/Generator startup)	DO3-NO	Digital output 3 - Normal Open	• DO3 interface can be used for controlling generator start in two-wire start mode. • DO3 have a contact capacity of 30 Vd.c./1 A. • NO/COM is normally open contact and NC/COM is normally close contact.
	DO3-COM	Digital output 3 - Common	
	DO3-NC	Digital output 3 - Normal Close	
DO2 (Dry contact 2)	DO2-NO	Digital output 2 - Normal Open	• DO2 is used for the output of the contactor status feedback signal for the Generator. • DO2 have a contact capacity of 30 Vd.c./1 A.
	DO2-COM	Digital output 2 - Common	
DO1 (Dry contact 1)	-	-	• DO1 is used for the output of the contactor status feedback signal for the grid. • DO1 has a contact capacity of 250 Va.c./1 A or 30 Vd.c./1 A.
	DO1-NO	Digital output 1 - Normal Open	
	DO1-COM	Digital output 1 - Common	

Appearance 2



Label		Definition	Description
FE (Network cable interface)	FE1	Fast Ethernet 1	Used to connect an inverter.
	FE2	Fast Ethernet 2	Used to connect an Sigen EV AC Charger, inverter, router and so on.
(Reserved) 485 (RS485 interface)	PE	PE signal shielding ground	Used to connect the equipment over RS485.
	485-A	RS485 signal 2_A+	
	485-B	RS485 signal 2_B-	
(Reserved) DI1	GND	Signal GND	(Reserved)
	DI1	Digital input 1	
DI2	DI2	Digital input 2	- DI2 can be used to connect the feedback signal of the external Automatic Transfer Switch (ATS) to identify whether the gateway "grid port" is powered by the grid or the generator. - Low impedance input (short circuit on ATS relay) indicates the power grid. High impedance input (open circuit on the ATS relay) indicates the Generator.
	GND	Signal GND	
(Reserved) DI3	DI3	Digital input 3	(Reserved)
DI4	DI4/SPD	Digital input 4 / Surge protection device	DI4 support surge protection device status feedback input signal, among others.
	GND	Signal GND	
DO1 (Dry contact 1)	DO1-NO	Digital output 1 - Normal Open	- DO1 is used for the output of the contactor status feedback signal for the grid. - The contact capacity of 24 Vd.c./40 mA.
	DO1-COM	Digital output 1 - Common	
DO2 (Dry contact 2)	DO2-NO	Digital output 2 - Normal Open	- DO2 is used for the output of the contactor status feedback signal for the Generator. - DO2 have a contact capacity 24 Vd.c./40 mA.
	DO2-COM	Digital output 2 - Common	
DO3/GEN (Dry contact 3/Generator startup)	DO3-NO	Digital output 3 - Normal Open	- DO3 interface can be used for controlling generator start in two-wire start mode. - DO3 have a contact capacity of 24 Vd.c./40 mA. - NO/COM is normally open contact and NC/COM is normally close contact.
	DO3-COM	Digital output 3 - Common	
	DO3-NC	Digital output 3 - Normal Close	
(Reserved) DO4 (Dry contact 4)	DO4-NO	Digital output 4 - Normal Open	(Reserved)
	DO4-COM	Digital output 4 - Common	
	DO4-NC	Digital output 4 - Normal Close	


5.6.1 Connecting RJ45 Network Cable



5.6.2 Connecting DI, DO Cable

Tips

DI and DO interfaces are available in two appearances. Please make connections based on your actual needs. For details, refer to "5.6 Introductions to FE, RS485, DI, and DO Terminals."




5.7 Installing Inner panel

Check the following items against the provided table, tighten routing holes, and install the protective covers.


S/N	Check Item
1	The equipment has been securely installed.
2	Ground cables, DC cables, signal cables, etc. are installed accurately without leftovers.
3	All screws or terminal blocks on the device have been installed in place and are not loose.
4	There are no sharp spikes or acute angles at the cut point of the cable tie.
5	The Gateway protective cover is locked.
6	There is no construction left inside or outside the equipment.

Tighten each routing hole




Caution

Measure the voltage of the switch QF1 on the power grid side and check that the measured value is within the allowable range. Ensure that the cable is connected properly, tighten routing holes, and install protective covers.



6 Equipment Power-On



SGA1IN00021

Tips

- Turn on the front switch of the equipment.
- There is a risk of electric shock if the Gateway is left ungrounded.
- If the surge protective device is not switched on, failure of surge protection may lead to damage to household loads and Gateway.



Caution

Do not turn on the miniature circuit breaker when it is not connected to its corresponding device.

1

- 1 Switch on the miniature circuit breaker (Surge Protection Device) QF6.
- 2 Switch on the miniature circuit breaker (Power grid) QF1.
- 3 Switch on the miniature circuit breaker (Inverter) QF3 or QF4.
- 4 Wait until inverter is powered on.
- 5 (Optional) Switch on the miniature circuit breaker (Smart loads/Generator) QF2.
- 6 Switch on the miniature circuit breaker (Backup household loads) QF5.

2

Upon completion of the operation, close the front panel of the Gateway and lock the sides with the key delivered with the case; the power-on is completed.



Caution

After each wiring change, please perform a wiring check on the mobile app to ensure proper connection before proceeding with subsequent operations.

Sigenergy Technology Co., Ltd.



Website	LinkedIn	YouTube
---------	----------	---------

www.sigenergy.com



Copyright © Sigenergy Technology Co., Ltd. 2025. All rights reserved.

Description in this document may contain predictive statements regarding financial and operating results, product portfolio, new technology, configurations and features of product. Several factors could cause difference between actual results and those expressed or implied in the predictive statements. Therefore, description in this document is provided for reference purpose only and constitutes neither an offer nor an acceptance. Sigenergy Technology Co., Ltd. may change the information at any time without notice.